



* DIN LS spiegelbildlich / Left hand mirror image / Côté gauche inversé en miroir / Página izquierda en reflejo / Linkerkant spiegelbeeld



G = Griffhöhe / Handle position / Hauteur de poignée / La manilla / Krukhoogte


* DIN LS spiegelbildlich / Left hand mirror image / Côté gauche inversé en miroir / Página izquierda en reflejo / Linkerkant spiegelbeeld




G = Griffhöhe / Handle position / Hauteur de poignée / La manilla / Krukhoogte

* = für Magnetclip / for magnetic clip / pour clip magnétique / para clip magnético / voor magnetische clip



* DIN LS spiegelbildlich / Left hand mirror image / Côté gauche inversé en miroir / Página izquierda en reflejo / Linkerkant spiegelbeeld





* DIN LS spiegelbildlich / Left hand mirror image / Côté gauche inversé en miroir / Página izquierda en reflejo / Linkerkant spiegelbeeld





* DIN LS spiegelbildlich / Left hand mirror image / Côté gauche inversé en miroir / Página izquierda en reflejo / Linkerkant spiegelbeeld





A - A





B¹ - B¹





B² - B²





C¹ - C¹




C² - C²



C³ - C³



D - D



E - E

- B¹ - B¹ = Abdeckkappe / cap / capot de recouvrement / tapa embellecor / afdekplaat
B² - B² = Magnetauslöser / magnetic trigger / déclencheur magnétique / disparador magnético / magneet activeering
C¹ - C¹ = Einsatzwinkel / Latch plate / Angle d'insertion / Resbalon / Inzethoek
C² - C² = Türöffner / Electric release / Gâche électrique / Cerraderos electricos / Electronische deuropenener
C³ - C³ = Tagesfalle / Daytime latch / Gâche journalière / Pestillo día / Dagschoot

